

6 Channel Voltmeter with Automatic Data Logging

by Softmark

Fast logging of data with the 6 Channel Voltmeter Card

Version 6.0 of the software for the 6 Channel Voltmeter Card with Automatic Data Logging has faster logging and the logging intervals start at 1 sec (if you require a smaller interval, please contact Softmark). All analog inputs are logged to text file c:\acq8.txt. This file can be easily exported to MSExcel if required.

Figure 1 below shows how to select the faster logging option.



Figure 1. Selecting the faster logging option.

After you press the “Start Logging” button, all data is appended to the c:\acq8.txt file. You can view this file automatically or manually. Please note that the next logging session will delete the contents of the previous acq8.txt file. The best option is to rename this file if required.



Figure 2. Virtual panel used for logging data